POKYNY PRE POUŽÍVANIE BATÉRIÍ

- Batérie nerozoberajte, nehádžte do vody a ohňa, neskratujte jej póly a ani inak batériu nepoškodzujte.
- Vždy odpojte batériu ihneď po použití napájaného zariadenia (napr. airsoft zbrane), po nabíjaní a počas pohotovostného režimu uchovávajte batériu v chladnom a suchom prostredí.
- Batérie nepoužívajte a ani nenechávajte v blízkosti zdroja tepla, ako je oheň alebo ohrievač.
- Batérie nabíjajte len príslušnými nabíjačkami (napr. Li-Po batérie môžu byť nabíjané len nabíjačkami na to určenými, nesmú sa nabíjať napr. nabíjačkami pre batérie Ni-Mh).
- Počas nabíjania a používania batérie sledujte jej teplotu, ak by dochádzalo k citeľnému prehrievaniu batérie, prestaňte ju používať, alebo ju odpojte od nabíjačky.
- Neodporúča sa nabíjať batérie bez dozoru.
- Ak batéria zväčší svoj objem (nafúkne sa), prestaňte ju používať, môže byť poškodená.
- Batérie typ Li-Po nikdy nevybíjajte úplne, môžete ich nenávratne poškodiť.
- Niektoré airsoft zbrane najmä zo sérií PROLINE môžu byť vybavené pokročilou elektronikou (ECU, MOSFET, snímače, čipy...), ktorá môže vybíjať batériu aj vtedy, keď sa zo zbrane nestrieľa. Preto, ak zbraň nepoužívate, batériu odpojte.
- Batériu inštalujte do zariadenia v súlade s návodom na použitie zariadenia.

INSTRUCTIONS FOR USE OF BATTERIES

- Do not disassemble the battery, throw it into water or fire, short-circuit its terminals or otherwise damage the battery.
- Always disconnect the battery immediately after using a powered device (e.g. airsoft guns), after charging and during standby mode, store the battery in a cool and dry place.
- Do not use or leave the battery near a heat source, such as a fire or heater.
- Charge the battery only with appropriate chargers (e.g. Li-Po batteries can only be charged with chargers designed for this purpose, they must not be charged, for example, with chargers for Ni-Mh batteries).
- Monitor the temperature of the battery during charging and use; if the battery noticeably overheats, stop using it or disconnect it from the charger.
- It is not recommended to charge the battery without supervision.
- If the battery increases in volume (swells), stop using it, it may be damaged.
- Never fully discharge Li-Po batteries, as this can cause permanent damage.
- Some airsoft guns, especially the PROLINE series, may be equipped with advanced electronics (ECU, MOSFET, sensors, chips...) that can drain the battery even when the gun is not being fired. Therefore, disconnect the battery when not in use.
- Install the battery into the device in accordance with the device's user manual.